




## SILHOUETTE CAMEO 3

When loading the mat align it with the arrows on your machine.



Once powered on use the touch screen to load and unload the mat.




On the right side of the machine you will find the power button and ports for power cord and USB.



You will find storage drawers under the machine.



Adjust the rollers on the right depending on your mat or material size.



The Silhouette Cameo 3 comes with an auto blade that adjusts cutting depth on it's own

